



- 1 Locate Alan bolts in covers and remove. Assemble bracket for L or R using hoes under seat.
- 2 Assemble Stand-off assembly.
- 3 Assemble two brackets as shown.
- 4 Attach bracket to chair. Longer bolt at the bottom junction.
- 5 Assemble GCS with mixed Bag Tee and Scavenger to GCS bracket as shown.
- 6 Attach mixed gas and scavenger hoses to back of the GCS.

