



NOTE: without the ¾" bracket, use the 20 mm bolts. With the bracket use the 30 mm bolts.

- 1** Locate this bolt pattern under the seat.
- 2** Either: A) Install two 20 mm screws into the two holes indicated, OR B) Remove two existing screws and use the 30 mm screws to replace them to install the mounting bracket.
- 3** Assemble GCS with mixed Bag Tee and Scavenger to GCS bracket as shown.
- 4** Attach mixed gas and scavenger hoses to back of the GCS.

