



- 1 Locate available female threads under the chair arm.
- 2 Install the chair bracket with a single screw as shown.
- 3 Assemble GCS with mixed Bag Tee and Scavenger to GCS bracket as shown.
- 4 Attach mixed gas and scavenger hoses to back of the GCS.

