



**1** Locate available mounting bolts under the chair seat.



**2** Install the chair bracket with a single screw as shown.



**3** Assemble GCS with mixed Bag Tee and Scavenger to GCS bracket as shown.

**4** Attach mixed gas and scavenger GCS to the mounting bracket.

**5** Attach mixed gas and scavenger hoses to back of the GCS.

