



- 1 Remove seat cushion.
- 2 Locate two screws shown & remove.
- 3 Install the chair bracket using the 1" screws as shown.
- 4 Assemble GCS with mixed Bag Tee and Scavenger to GCS bracket as shown.
- 5 Attach mixed gas and scavenger hoses to back of the GCS.

